

PROGRAMMING YOUR PBTV REMOTE FOR POWER & VOLUME

START WITH TV TURNED ON

CODE SEARCH METHOD

Press and hold Setup **3** until LED at the top of the remote blinks twice.

Press and release TV **1** button.

Press and hold OK **2** button until the device turns off.

IF THE VOLUME WORKS, DO THE FOLLOWING STEPS:

LOCK THE VOLUME METHOD

Press the TV **1** button.

Press and hold Setup **4** until TV **1** button blinks twice.

Press Volume + **5** button one time.

Press the TV **1** button.

Press the STB **6** button.

