

TV
Controls TV functions

POWER
Turns components On/Off

MENU
Displays main menu

OK
Press when you want to select a program or highlighted object

GUIDE
Displays program guide

PAGE BACK/FORWARD
Scrolls side-to-side from the current page in the guide

RED/GREEN/YELLOW/BLUE BUTTONS
For office use only

VOLUME +/-
Volume control

NUMBER KEYS
Used for entering channel numbers

DELETE
Deletes single character in text entry boxes

INPUT
Switches between audio/video inputs on your TV

STB
Used for Set Top Box functions

PLAYBACK CONTROLS
For use with DVR/VOD functions

INFO
Displays information about the current program

ARROWS
Allows you to scroll through the guide and menu

EXIT
Exits the guide and menu

PAGE UP/DOWN
Scrolls Up/Down through the current page in the guide

CHANNEL +/-
Changes channels on the STB

LAST
Returns to the previous channel

CLOSED CAPTIONING
Enable/Disable Closed Captioning