PROGRAMMING YOUR PBTV REMOTE FOR POWER & VOLUME

START WITH TV TURNED ON

CODE SEARCH METHOD

- The following steps need to be done in quick succession.
- Press and release the TV ❶ button.
- Press and hold the RCU SETUP ❷ until the TV button blinks twice.
- Enter in **9-9-1**.
- Press and release the CH+ or CH - ❹ until the TV shuts off. When you are doing the CH+ or CH-, you must do it slow enough to react when your TV shuts off. Be patient, you may have to hit CH+ or CH- up to 300 times.
- Press the RCU SETUP ❷ button to store the code for the TV. The TV button will blink twice. The remote is now ready to operate the TV.
- Test the power and volume

LOCK POWER BUTTON FOR TV

- The following steps need to be done in quick succession.
- Press the STB ❻ button.
- Press and hold the RCU SETUP ❷ until the LED button blinks twice.
- Enter in **9-9-5**.
- Press the POWER ❸ button.
- Press the TV ❶ button.
- Press and hold the RCU SETUP ❷ until the TV ❶ button blinks twice. Nothing happens to the TV during this process.
- Press the TV ❶ button.
- Press the STB ❻ button.

BOTH STEPS NEED TO BE DONE WITH NEW REMOTES